



AIRCRAFT TECHNICAL PUBLISHERS

MANUFACTURER: NARCO

MODEL: DME 890 DISTANCE MEASURING EQUIPMENT

TYPE OF PUBLICATION: MAINTENANCE MANUAL

GENERAL INDEX

	<u>ATP GRID</u>
ALPHABETICAL INDEX	NIC
FIGURE/TABLE INDEX	NIC
TITLE PAGE	1B02
LIST OF EFFECTIVE PAGES	1B10
RECORD OF REVISIONS	1B04
RECORD OF TEMPORARY REVISIONS	NIC
SERVICE BULLETIN LIST	NIC
TABLE OF BLOWUPS	1A03

<u>CHAPTER/SECTION</u>	<u>DESCRIPTION</u>	<u>ATP GRID</u>
SECTION I	INTRODUCTION	1C04
SECTION II	INSTALLATION	1C06
SECTION III	CIRCUIT DESCRIPTION	1D02
SECTION IV	MAINTENANCE	1G02
SECTION V	MECHANICAL PARTS LIST	1J02
SECTION VI	SCHEMATIC ELECTRICAL PARTS LIST	1K02
	MODIFICATION INSTRUCTIONS	1M02

TABLE OF BLOW-UPS

<u>FIGURE</u>		<u>PAGE</u>	<u>ATP GRID</u>	<u>BLOW-UP FICHE</u>
2-3	Unit Installation Drawing	2-7	1C11	
2-11	UDA-3 Antenna	2-15	1C20	NC J402
	VOR/DME Channel Pairing and Operating Frequencies	3-3	1D06	
	VOR/DME Channel Pairing and Operating Frequencies	3-4	1D07	
	X/Y Modes Frequency Correlation Summary	3-5	1D08	
4-7	Gas Discharge Display Internal Wiring			
4-8	Functional Checkout Flow Chart	4-16	1G19	
4-9	Transmitter Trouble Isolation Flow Chart	4-17	1G20	
4-10	Receiver Trouble Isolation Flow Chart	4-18	1G21	
4-11	Power Supply Trouble Isolation Flow Chart	4-19	1G22	
4-12	Display Trouble Isolation Flow Chart (Sheet 1 of 2)	4-20	1G23	
4-13	Distance, Frequency, Ident, and Remote Channel Isolation Flow Chart	4-23	1H05	
4-14	Synthesizer Isolation Flow Chart	4-25	1H09	
		4-27	1H13	
6-1	Internal Wiring (Interconnect) Diagram			
6-2	Trans/Mod/Preselector/Mixer Electrical Parts List	6-3	1K07	
	Electrical Parts List	6-5	1K11	
	Electrical Parts List	6-6	1K17	
6-3	Main PC Board	6-8	1K19	
6-4	Power Supply and Right Side Panel	6-9	1L01	
6-5	IF Receiver	6-11	1L09	
		6-13	1L14	NC J403

NARCO AVIONICS

DME 890

DISTANCE MEASURING EQUIPMENT



MAINTENANCE MANUAL

03314-0600

 NARCO AVIONICS INC.

FORT WASHINGTON, PENNSYLVANIA, 19034 U.S.A.

NARCO AVIONICS

DME 890

(MM - 03314-0600 dtd 12/80)

IS YOUR MANUAL COMPLETE?

This page is provided, and updated as necessary, with each printing and supplement issued. As all pages are dated, it is easy to verify if the manual on hand is complete and current. Page numbers prefixed by a "B" are pages that are intentionally blank.

A complete page by page check can be made by comparing the page number and date below to that of each page. A quick check can be made by "eying" the bar(s) at the base of this page against the

bottom edge of the whole manual. One bar on this page indicates one set of supplemental pages were issued; additional bars... additional supplements. Generally one will eye at least one bar per supplement.

It should be noted that the pages of Sections 1 and 2 may be dated prior to the cover date of the Maintenance Manual as those Sections are the Installation Manual which always precedes the Maintenance Manual.

PAGE	DATE	PAGE	DATE	PAGE	DATE	PAGE	DATE
Cover	12/80	3-11	12/80	3-49	12/80	5-1	12/80
A	5/81	3-12	12/80	3-50	12/80	B5-2	
i	12/80	3-13	12/80	3-51	12/80	5-3	12/80
Bii		3-14	12/80	3-52	12/80	5-4	12/80
1-1	12/80	3-15	12/80	3-53	12/80	5-5	12/80
1-2	12/80	3-16	12/80	B3-54		5-6	12/80
2-1	5/81	3-17	12/80	4-i	12/80	5-7	12/80
2-2	5/81	3-18	12/80	4-ii	12/80	5-8	12/80
2-3	12/80	3-19	12/80	4-1	12/80	5-9	12/80
2-4	12/80	3-20	12/80	4-2	12/80	5-10	12/80
2-5	12/80	3-21	12/80	4-3	12/80	5-11	12/80
B2-6		3-22	12/80	4-4	12/80	5-12	12/80
2-7	12/80	3-23	12/80	4-5	12/80	5-13	12/80
B2-8		3-24	12/80	4-6	12/80	5-14	12/80
2-9	12/80	3-25	12/80	4-7	12/80	5-15	12/80
2-10	12/80	3-26	12/80	4-8	12/80	5-16	12/80
2-11	5/81	3-27	12/80	4-9	12/80	6-i	12/80
2-12	5/81	3-28	12/80	4-10	12/80	B6-ii	
2-13	12/80	3-29	12/80	4-11	12/80	6-1	12/80
2-14	12/80	3-30	12/80	4-12	12/80	6-2	12/80
2-15	12/80	3-31	12/80	4-13	12/80	6-3	12/80
2-16	12/80	3-32	12/80	4-14	12/80	B6-4	
2-17	12/80	3-33	12/80	4-15	12/80	6-5	12/80
2-18	12/80	3-34	12/80	4-16	12/80	6-6	12/80
2-19	12/80	3-35	12/80	4-17	12/80	B6-7	
B2-20		3-36	12/80	4-18	12/80	6-8	12/80
3-i	12/80	3-37	12/80	4-19	12/80	6-9	12/80
3-ii	12/80	3-38	12/80	4-20	12/80	6-10	12/80
3-1	12/80	3-39	12/80	4-21	12/80	6-11	12/80
3-2	12/80	3-40	12/80	B4-22		6-12	12/80
3-3	12/80	3-41	12/80	4-23	12/80	6-13	12/80
3-4	12/80	3-42	12/80	B4-24		6-14	12/80
3-5	12/80	3-43	12/80	4-25	12/80		
3-6	12/80	3-44	12/80	B4-26			
3-7	12/80	3-45	12/80	4-27	12/80		
3-8	12/80	3-46	12/80	B4-28			
3-9	12/80	3-47	12/80	5-i	12/80		
3-10	12/80	3-48	12/80	B5-ii			

